# How To Use Mobile Phone APP

1. Search for "ThinkDiag+" in GooglePlay or "ThinkDiag" in App store and download it.



2. Register account with Email.



3. Go to the homepage and select



4. Select the THINKTPMS module

5. Enter the Serial Number and Activation Code to activate the device.



6. After the binding is successful, the program will be updated automatically.



7. Select brand, model, year, frequency band of the tire pressure sensor.



8. Using THINKTPMS G2, it supports activating the tire pressure sensor, reading the version number, and reading the tire pressure value. For online programming function and tire pressure learning function, please purchase THINKDIAG connector or other THINKCAR diagnostic equipment.

## Screen 1

**TPMS**

Active | Programming | Learning



FL    FR

RL    RR

## Screen 2

**TPMS**

Active | Programming | Learning



FL    FR

RL    RR

Auto    Manual    Replication

## Screen 3

**TPMS**

Active | Programming | Learning



FL    FR

RL    RR

## Screen 4

**TPMS**

Active | Programming | Learning

Sensor Manufacture: Huf/Beru
Sensor frequency: 433MHz
Sensor part number: 4F0907275D
Print No.: RDE011